# **HiCOZY**

# **USER MANUAL**

PORTABLE AIR COOLER

Tricoo-S1



VERSION: V1.2

# **CATALOGUE**

INTRODUCTION	03
WARNING ·	04
SPECIFICATIONS	05
DIAGRAM ·	06
INSTRUCTIONS	08
MAINTENANCE	12
TROUBLESHOOTING/FAQ ·	13
RECYCLING ·	14
WARRANTY PERIOD · · · · · · · · · · · · · · · · · · ·	14

# INTRODUCTION

Thank you for purchasing the HiCOZY Portable Air Cooler. This product provides personal cooling and air humidifying. If you have any questions about or issues with your new product, please contact us via <a href="mailto:support@hicozy.com">support@hicozy.com</a>.



Please fully read and understand this manual before using and keep this manual for future reference.

## **WARNING**

- Please only use the included HiCOZY adapter to charge the cooler
- To reduce the risks of fires and electric shocks, any disassembly of this product is forbidden.
- It is normal to have condensation droplets accumulate on the Mist Port in humid environments. Please use the low mode if it persists.
- Please only fill the reservoir with low-temperature (50~95 °F/ 10~35 °C) drinkable water.
- Please do not place any foreign objects in the atomizer, such as essential oil, perfume, ice cube, etc.
- Place the product on an even surface to avoid leakage from the water tank.
- Do not place the product in dusty environments, doing so may damage the product.
- Ensure the product is operated in a well-ventilated environment before use. There should be 2 inches of clearance all around it.
- · Keep the product away from the heat sources to avoid deformation.
- · Do not allow children to use the product without supervision.
- The device's electronics are located at its bottom. Please do not disassemble the bottom or smash it violently.
- To ensure the freshness of the air, regularly wash the water tank.
- · Do not touch the power source or power port with wet hands.

- Do not crush or turn the product upside down. Do not place anything heavy on it.
- · Do not immerse the product in water or any liquids.
- If the product is about to be idle for a long time, please disconnect the power, drain the water tank and store the unit in a well-ventilated place.

# **SPECIFICATIONS**

Product Portable Air Cooler

Model Tricoo-S1

Input Voltage AC 100-240 V, 50/60 Hz, 0.8 A

Working Voltage DC 24 V, 1 A

Power Rating 24 W

Water Tank Capacity 650 mL


Fan Mode 3 Speeds

Mist Mode 2 Modes

Timer 1 h, 2 h, 4 h

Certifications FCC, UL

# **DIAGRAM**



- 1 Mist Port
- ⑤ Fan

(9) Timer Button


2 Vents

- (6) Power Port (10) Indicator

- ③ Water Tank
- (7) Fan Button

(4) Pads

(8) Mist Button



- 1 Ambient Light
- ② PogoPin Port
- 3 Maximum Water Level
- 4 Atomizer
- ⑤ Power Adapter

# **INSTRUCTIONS**

#### ADD WATER

Remove the body first, then slowly fill the water tank with an appropriately-sized container.


Do not exceed the Max Water Level.



**Note:** Do not add ice to the atomizer. Do not allow water to contact any of the electronics.


#### INSTALLATION

Clean the droplets on the PogoPin port. Install the body on the water tank, aligning the PogoPins together to ensure a correct installation.




#### POWER THE PRODUCT

Put the product on a table, then connect one end of the power adapter to an AC socket and the other end to the product's power port.




#### TURNING THE FAN ON/OFF

- Press the Fan Button once to start at the 1st speed and enter Mist Mode 2 by default. The ambient light will light up.
- · Press twice to set it to speed 2.
- · Press three times to set it to speed 3.
- · Press four times to turn it off.



#### TURNING THE MIST ON/OFF


- · Press the Mist Button once to start in Mode 2.
- · Press the Mist Button twice to enter Mode 1.
- · Press the Mist Button three times to turn it off.



#### TURNING THE TIMER ON/OFF


Press the Timer Button to start the timing function. You can set the Air Cooler to run for 1. 2 or 4 hours.

After the set time has elapsed, the Portable Air Cooler will shut off. Press the Timer Button again to turn off the timer function.




#### TURNING THE AMBIENT LIGHT ON/OFF

- Press and hold the Mist Button for 3 seconds to turn on the ambient Light.
- Press and hold the Mist Button again for 3 seconds to turn the ambient light off.



#### ADJUSTING THE AIR DIRECTION

Adjust the vents upward or downward to change the air direction.




# **MAINTENANCE**

Disconnect the power before maintaining or cleaning the product.

## CLEANING THE WATER TANK

After removing the body, use a wet towel to clean the water tank. Do not use a wet towel to clean the connector and the atomizer module.



# TROUBLESHOOTING/FAQ

#### BUTTONS FAIL TO WORK

- · Check if the device is receiving power.
- · Check if the power cord is connected securely.

#### FLASHING MIST BUTTON INDICATOR

Insufficient water, please add water.

#### THE MIST IS NOT COMING OUT

- · Insufficient water, please add water.
- · Check if the body is correctly connected to the water tank.
- · Check if the atomizer is damaged.
- · Check if the PogoPin port is damaged.
- If the atomizer is dirty, please use a cloth dipped in alcohol to wipe it.

#### THE FAN DOES NOT WORK

Check if the fan is blocked by any foreign objects.

#### THERE IS CONDENSATION DROPPING FROM THE MIST PORT

The product can be used as a humidifier. If the weather is too humid, excess condensation will occur. To reduce this, turn off the mist function or change to Mode 1.

## RECYCLING

You may dispose of the product when its service life has ended, please recycle the recyclable parts according to local guidelines.

# WARRANTY PERIOD

#### 1-YEAR LIMITED WARRANTY FROM HICOZY

Each HiCOZY Portable Air Cooler will be free from defects in material and workmanship. This warranty does not cover damage from neglect, misuse, contamination, alteration, accident, or abnormal conditions of operation or handling. This warranty covers the original purchaser only and is not transferable. HiCOZY always wants to provide our customers with excellent products and customer service.

Questions or concerns? We're happy to help. Please contact us via support@hicozy.com.

